
Contents

Helicopter arrivals and departures chart	1
Arrivals	
Departures	
Appendix 1 - Restricted Area (Temporary) RA (T)	
Appendix 2 Event airfield plate	4

Helicopter arrivals and departures chart




Arrivals

- 1. MONITOR Sywell Radio on 122.705 MHz for aerodrome details, no radio call required.
- 2. All arrivals/departures to route in/out via Heli East towards the Eastern Aerodrome boundary avoiding all villages and fixed wing patterns.
- 3. Arrivals not above 500ft QFE, beware of departures climbing to 1000ft QFE within the RA(T).
- 4. At Heli East, make an RTF call "Helicopter type, full registration, Heli East QFE xxxx"
- 5. Arrivals make an approach to the Eastern boundary south of the northern windsock. Do not infringe the 21 L (Grass) approach or 03R (Grass) climb out.
- 6. Park in a row adjacent to the aerodrome boundary hedgerow,
- 7. Ensure adequate rotor separation.

Departures

- 1. Start with caution monitoring Sywell Radio on 122.705 MHz.
- 2. When ready for departure, make an RTF call "Helicopter type, full callsign, ready for departure Heli East, QNH xxxx"
- 3. Depart climbing to 1000ft QFE with caution, beware of inbound helicopters not above 500ft QFE. 1.When clear of the RA(T) continue en-route.

Appendix 1- Restricted Area (Temporary) RA (T)



Appendix 2 Event airfield plate

