


AIRFIELD NAME AND ICAO		July 20	July 20 POPHAM		EGHP	S
CALLSIGN (A/C RADIO)			Popham Radio		129.800	
CALLSIGN (ES/VATSIM)		EGHP_R_TWR		Elev. 547ft		
LOCATION		Lat N051.11.36.000 Lo		Long W001.14.10.000	QFE= QNH-18HPscls	
LOCATION GEOGRAPHIC		14.5nm E of N from EGHI beside A303 2nm SW of M3 Jnctn 8				
CHART SOU	RCE PlanG3, F	SX, CIX links, E	EGHP Web site	e Overhead joins recomme	ended. <b>Especially if</b>	circuit busy
METAR	EGHI 130.370	RUNWAY 08/26, is the preferred runway. BOTH ARRIVAL/DEPARTURE ROUTES				
A/P	LGIII 150.570	OFFSET TO NORTH. 08-DO NOT OVERFLY THE GARAGE. FOLLOW ARROW IN GRASS				
NAV AIDS	NONE	26 -Avoid SILOS at safe height and avoid houses. Both, MINIMIZE Takeoff noise.				
RUNWAYS	Headings	Dimension	Surface	Runway 03/21 This runway		subject to
	08 / 26	914m x 25m	n Grass	maximum use rules (planning laws).		
	03/21	900m x 25m	n Grass	RUNWAYS ARE UNLICENSED		
AIRSPACE	CLASS G	Transition level 6000ft Airspace above is Class A. Base FL65				
CIRCUITS .	800ft QFE	ALL Circuits to the NW. 08 & 03 LH. 21 & 26 RH. OBSERVE STRICT NOISE ABATEMENT				
NO FLY	ODIHAM MATZ	MATZ Stub is 1.5nm NE. Local Villages and other Noise abatement areas. see charts below.				
HAZARDS	CAUTION STUE	ION STUD FARMS TO THE NORTH. ALL downwind legs MUST BE MINIMUM 800ft QFE.				
HELICOPTER OPERATIONS	Southern Approach. Approach to hold opposite centre of 08/26. CROSS ROAD AND RUNWAY WITH					
	EXTREME CAUTION.					
	Eastern Approach. Remain North of A303, not above 700ft QFE, SET DOWN East of 03/21 well clear of					
	Garage/offset approach (If active 08/26). Proceed with extreme caution.					
	Helicopters should park North of thresholds 26/03, well clear of taxiways around the trees. E.G. on					
	northern cross taxiway. Call for mobile bowser for refuel.					
SPECIAL	Fixed wing A/C. Fuel point, one way WESTERLY, Engines MUST BE shut down during refuelling.					
RULES	MAKE SURE EVERYONE ELSE KNOWS WERE YOU ARE and WHAT YOU ARE/GOING TO DO					
REMARKS	Airfield is close to northern end of Southampton CTA. Especially if departing South, expect control					
	from SOTON Radar. 120.225. IF TRAFFIC PERMITS, FXD WING A/C from the SOUTH may DEAD-SIDE					
	join, over the woods for 08/26 at 800ftQFE. KEEP Å SHARP LOOKOUT and announce.					







ABOVE: EUROSCOPE LAYOUT SHOWING TAXIWAYS; FLIGHT SIM USE ONLY. USE DEGNATORS TO LET OTHERS KNOW WHERE YOU ARE (AND ARE GOING).

NOTE: USE OF SUTHERN 08/26 TAXIWAY, NOT RECOMMENDED DUE CLEARANCE FROM HEDGEROW.

"If you arrive when we are closed, leave your landing fee(and registration) in an envelope, posted through the Club House door."

PILOTS: PLEASE PUT YOUR A/C CALLSIGN AFTER YOUR NAME. NOT TO BE USED FOR REAL WORLD OPERATIONS