

QNH**QFE****WIND****/**

AIRFIELD NAME AND ICAO	CAMPBLETOWN		EGEC
CALLSIGN (A/C RADIO)	Campbletown Information		125.900
CALLSIGN (ES/VATSIM)	EGEC_I_TWR		Ground. ----
LOCATION	Lat N055.26.15	Long W005.41.17	Elev. 182ft
LOCATION GEOGRAPHIC	3nm W of Campbletown		Conspicuity ---
CHART SOURCE	NATS		App.---
METAR AIRPORT	EGAC Belfast Hbr. 136.620 Set Belfast region press		QFE= QNH(METAR) -6 HPscIs
NAV AIDS (FSX / PLANG3)	NDB/ CBL; 380kHz	VOR/MAC 116.000; IM r29, slight offset to south	
RUNWAYS	Headings	Dimension	Surface & notes
	11 / 29	1750m x 46M	Asphalt NB 2/3 of original runway
AIRSPACE/TRANS ALT QNH	CLASS G	Trnstrn level 3000ft	Airspace above Class C Base E.FL105 W.FL195
CIRCUITS HEIGHT / DIR.	1000ft QFE. ALL CIRCUITS to the NORTH; 11 LH, 29 RH		
NO FLY AREAS	The town of Campbletown		
LOCAL HAZARDS	Oct > Mar. GEESE . Wandering Deer. Southern Parallel taxiway NO LONGER PART OF AIRFIELD 8ft high perimeter fence at both ends of USABLE runway - see chart below. ALL grass areas are liable to water-logging, easpecially after rain/low cloud/fog conditions.		
HELICOPTER OPERATIONS	Operate as fixed wing, Exercise extreme caution near limits of reduced airfield boundary, buildings and other A/C IF APRON IS IN USE BY FIXED WING A/C, use the nearest 'dispersal area'.		
SPECIAL RULES	RNAV approaches by A/P Authority approved operators, ONLY. NO TRAINING (T&Gs) NO DEPARTURES IF VISIBILITY 400m or less		
REMARKS	Almost 50% of the original RAF base is now OUTSIDE the A/F boundary. CHECK the CHART You cannot taxi WEST of Taxiway C. CAUTION Boundary fence next to HOLD C.		
ALL PILOTS: PLEASE PUT YOUR A/C CALLSIGN AFTER YOUR NAME.			

