AIRFIELD NAME AND ICAO	BLACKPOOL			EGNH	N	
CALLSIGN (RADIO)	Blackpool Tower			118.405 / 119.955	•	
CALLSIGN (ES/VATSIM)	EGNH_TWR		Ground			
LOCATION	Lat N053.46.18.000 Long W003.01.43		.000	Elev. 172ft		
LOCATION GEOGRAPHIC	2.6 nm SSE of Blackpool			Conspicuity		
CHART SOURCE	NATS			App. 119.955		
METAR AIRPORT	EGNH; 127.205		My QFE= QNH(METAR) -4 HPscls			
NAV AIDS (FSX / PLANG3)	NDB/	kHz	DME/	MHz		
RUNWAYS	Headings	Dimension	Surface & notes			
	10 / 28	1869m x 40m	Asphalt	sphalt		
	13 / 31	1004m x 23m	Asphalt			
AIRSPACE/TRANS ALT QNH	CLASS G	Transition level 3000ft	Airspace above is Class C Base Alt 19500; London FIR			
CIRCUITS HEIGHT QFE / DIRS	1500ft	10, 13LH; 28, 31RH;				
		10 / 28 Deps. Runwa	s. Runway hdg to 1500ft QNH before turn.			
NO FLY AREAS						
LOCAL HAZARDS	Flocks of Geese and Gulls regularly transit N/S,S/N up to 2000ft					
	Taxiing and parking on grass areas is prohibited.					
	IN/OUT routing may include – Stannes Pier; Gasometers; Blackpool Tower.					
HELICOPTER OPERATIONS	3 'H' aiming points are located on the A/D.					
	1) H NORTH. 140m West of control tower.					
	2) <b>H SOUTH.</b> 75m SE of hold point D3. 3) H EAST. 158m E SE of control Tower; Helicopters MAX 2.6 Tonnes.					
	AIR TAXIING on aprons ONLY if approved by ATC.					
SPECIAL RULES	Non Radio, PPR; ALL A/C require flt plans; ALL A/C call for start, with					
position.						
	Runway 13 / 31 NOT available to JET or JET-Prop A/C; For fuel, park facing SOUTH to the EAST of the pumps Pilots should not request start up or taxi unless ready to do so.					
REMARKS	WARTON MATZ cuts the southern half of the ATZ; Est sfc; Wst; 1000ft;					
	Inbnds from south should contact Warton LARS, 129.52 if available.					
	GA inbound for fuel, notify Twr, initial call; Do not request taxi until ready to					
	move;					

## ALL PILOTS:

WHEN RECEIVING A SERVICE VIA CIX TEAMSPEAK PLEASE PUT YOUR A/C CALLSIGN AFTER YOUR NAME.