

QNH**QFE****WIND****/**

AIRFIELD NAME AND ICAO	Benbecula		EGPL
CALLSIGN (A/C RADIO)	Benbecula Tower/information		119.200
CALLSIGN (ES/VATSIM)	EGPL_TWR/EGPL_I_TWR		Ground.
LOCATION	Lat N057.28.50.000	Long W007.21.50.000	Elev. 19ft
LOCATION GEOGRAPHIC	West side of Benbecula Island		VFR Conspicuity ---
CHART SOURCE	NATS		App.
METAR AIRPORT	EGPL113.95?		QFE= QNH(METAR) - 0HPscls
NAV AIDS (FSX / PLANG3)	NDB; BBA;401KHz.		VOR; BEN; 113.95
RUNWAYS	Headings	Dimension	Surface & notes
	06 / 24	1836m x 46m	Asphalt; Preferred runways; Land 24; Dep. 06
	17 / 35	1220m x 46m	Asphalt
AIRSPACE/TRANS ALT QNH	CLASS G	Transition level 3000ft	Airspace above is Class C FL195
CIRCUITS HEIGHT / DIR.	BY PRIOR permission of ATC ONLY, as instructed.		
LOCAL HAZARDS	<p>ALL TAXIWAYS EXCEPT ALPHA ARE DISUSED and liable to be blocked or hazardous to A/C. The area 2.2nm WEST is an AIAA. Liable to be active by high speed, Mil A/C at low level. Including a large live bombing range to the SW. ATC will advise. USE MARKED TAXIWAYS AND RUNWAYS; all grass and other areas unsafe for a/c and vehs.</p>		
HELICOPTER OPERATIONS	As for fixed wing unless advised by Tower		
SPECIAL RULES	<p>When ranges are active, 06 Arr. and 24 Dep. may be restricted or disallowed by ATC. The A/F may be used by Mil A/C at any time, with or without ATC. Likewise Medivac and SAR operations. BOTH will take precedent over ALL other movements. Runway 17/35, restricted to use by GA A/C unless 06/24 unavailable, due weak paving. The A/F is NOT LICENCED for bad weather (RVR) operations.</p>		
REMARKS	<p>There is NO MARKED parking on the apron, due to wind changes. GA A/C are advised to park with respect to current and forecast wind direction. Visiting crew and passengers will be subject to local special security arrangements</p>		



QNH

QFE

WIND

/

ALL PILOTS: PLEASE PUT YOUR A/C CALLSIGN AFTER YOUR NAME.

